

## Where to find the asset tag on your machine

---

### Desktop Computers

The asset tag should be placed on the front side, bottom corner of desktops, above the model and serial number as pictured below.



### Small Form factors

Asset tags must be placed on the front of small form factors as these machines are typically placed in media carts. Please refer to the image below for exact placement.




## Laptops and PC Tablets -

Asset labels should be placed on the top of the laptop in the bottom left corner as pictured below.



## All-in-One Desktops

Asset label should be placed on the front of the PC between the speaker bar and monitor in the bottom left corner as pictured below.



## Mobile tablets & iPads

Asset labels should always be placed on the device itself and never on a protective case. Labels should be affixed to the back of the device in the most center below the camera as pictured below.



## Where to find the device model & serial number

---

### ThinkPAD

The product name is printed on the LCD Bezel of your machine

Product Name - X230



The serial number is printed at the bottom of your machine or beneath the battery. If the Machine Type model information is needed, it is located just right next to the serial number

- Serial Number - 7812AB3
- Machine Type - 2668
- Machine Type Model - 2668KHU

**Product number  
(Machine type - Model)**

Type 2668-KHU S/N 78-12AB3

**Serial number**

## Think Centre / Think Station

The product name is printed on the side or back of your machine

Product Name - M90z



The serial number is printed on the side or back of your machine. If the Machine Type model information is needed, it is located just right next to the serial number

- Serial Number - 2328X9N
- Machine Type - 8215
- Machine Type Model - 8215E1U


**Product number  
(Machine type - Model)**

TYPE 8215-E1U S/N 23-28X9N

**Serial number**

## IdeaPad and Lenovo Notebooks

The product name is printed on the label at the bottom of your machine.



**Product Name - Z575**

Lenovo IdeaPad Z575  
Model Name(型号/型号): 1299  
(输入)INPUT:20V  $\equiv$  3.25A  
輸入電壓/電流: 20V  $\equiv$  3.25A  
Mfg Date:11/06/21  
S/N: WB02367883  
MO: WB0106210V  
Factory ID: KS  
Manufactured for Lenovo  
(Singapore)Pte.Ltd  
Made in China 中国制造/中國製造

The serial number is printed on the label at the bottom of your machine.




### IdeaCentre and Lenovo desktops/ all-In-Ones

The product name is printed on the label at the rear chassis of your machine.



The serial number is printed on the label at the rear chassis of your machine.



SSXXXXXXXXX

**lenovo**  
Trademark of Lenovo

Marca Registrada  
Copyrighted code and parts contained herein  
©Copyright Lenovo, 2007. All rights reserved.

Machine Type 5985      100 127390-240V\*\*  
Model Number 59850000      105A  
S/N: 0000000000      504942

Warranty: 3Y3Y3M3D  
Product Name: Lenovo 3000 K190  
Manufactured for Lenovo (Singapore) Pte. Ltd.  
Product certified in Heather City, China  
Made in China

Assembleur officiel autorisé à la vente et à l'usage  
Assemblador autorizado para a venda e utilização  
Lathis on official authorized for sale and use

FC      UL US LISTED      CE      10      LENOVO 100 - 001, Class B      LENOVO 100 - 001, Class B

HP desktop systems should have a sticker on the top of the machine listing both the serial number and the model. A similar sticker should be on the bottom of the HP laptops.